

涂鸦智能窗帘电机

Zigbee 版


说明书



- - - 专 注 · 创 新 · 极 致 - - -

根据公司业务发展情况，产品可能不时调整，具体功能及内容也可能随之动态调整，公司不能保证相关包装及说明及时更新，顾客请以实际使用时的功能及内容为准。

结构说明




基本参数

产品型号	BMD900E	无线频率	2.4G/433MHz	最大宽度	12m
额定功率	45W/60W	最大载重	50Kg	防护等级	20IP
额定电流	0.14A	机身重量	1.05Kg	运行时间	>4min
额定扭矩	1.2Nm/2.0Nm	运行噪声	33dB	工作温度	-10℃~50℃
运行速度	14cm/s	最小宽度	0.9m	电源线类型	2芯
工作电压	100~240Vac 50/60Hz				


功能特点

- 轻触启动功能
- 停电手拉功能
- 遇阻停止功能
- 优雅运行
- 面料反弹修正功能
- 行程微调功能
- 电子记忆限位
- 远程控制
- 定时控制
- 语音控制
- 正反转设置
- 校准功能


电机安装



检查拔头锁杆是否在示意图位置,如果在图示右侧,请先拉动拔头锁杆的同时拨向左侧。




电机插入主传动箱。




拨动拔头锁杆至右侧,直到杆头掉进右侧限位孔为止。


电机拆卸




向下拉动拔头锁杆,使其顶端滑出限位孔。



拨动拔头锁杆至左侧。




取出电机。




⚠ 注意

- 按图示中的尺寸要求进行安装;
- 确保拔头锁杆在图示中的位置;
- 安装电机的天花板必须坚固,足够可承受包括导轨、电机、窗帘布在内的全部重量。


遥控对码



电机与遥控器对码



给电机通电




按下电机的功能键
3秒以上,指示灯长亮




按下遥控器的打开键,
对码成功

电机与遥控器解码




通电状态,按下功能键
3秒以上,待指示灯长亮



松手长按功能键5秒以
上待指示灯快速闪烁
完成清除功能

电机运行换向



功能键快按一次,再长按,
电机抖动,换向成功。




该产品使用涂鸦智能系统控制请下载涂鸦智能APP

电机联网



扫描二维码，下载安装涂鸦智能APP或者到手机应用市场上搜索下载，并注册账号登录。



快速短按3次电机的功能键，再长按1次并保持指示灯慢闪



打开涂鸦智能APP里[智能网关]点击[添加子设备]。注意如网关未配网请先执行网关组网操作。



选择“窗帘”，根据页面说明确认设备状态，点击确认进入连网。



输入密码，点击确认，进行配网。



等待连接成功，即可在APP上控制，可自定义设置名称。

解网方法:

智能开关解网方法有两种:

方法一:在手机APP上解除,进入要解除的设备,点击右上角,选择"解除设备";

方法二:连按三下复位键,再长按5秒至指示灯长亮

设备共享:

在涂鸦APP上进入设备,点击右上角的,选择“共享设备”,然后“添加共享”,将要共享的账号添加进去即可。

语音控制方法

涂鸦智能窗帘电机支持多种语音盒子控制,分别有: 天猫精灵 | 小爱同学 | 若琪 | Amazon | Google Home

- 1.将智能窗帘电机通过“涂鸦智能”APP联网;
- 2.将涂鸦智能的账号绑定到语音各自盒子的APP上,即可用相应的语音控制。

例如1：天猫精灵控制

- 1.将智能窗帘电机通过“涂鸦智能”APP联网;
- 2.打开“天猫精灵”APP。点击“我的”→“添加设备”,在绑定平台账号里找到“涂鸦智能”进行绑定。绑定后即可在天猫精灵上控制了。


例如2：小爱同学控制

- 1.将智能窗帘电机通过“涂鸦智能”APP联网;
- 2.打开“米家”APP。点击“我的”—“设置”—“实验室功能”—“第三方平台”—“添加”找到“涂鸦智能”进行绑定。
绑定后即可在小爱同学上控制了。

产品清单

- 1.智能窗帘电机一个;
- 2.电源线一条;
- 3.使用说明书一份。

界面说明



售后政策

三包规定

- 1. 自您签收次日起7日内, 本产品出现性能故障的情况, 经服务中心确定, 可免费享受退货或换货服务;
- 2. 自您签收次日起8日-15日内, 本产品出现性能故障的情况, 经服务中心确定, 可免费享受换货或维修服务;
- 3. 自您签收次日起36个月内, 本产品出现性能故障的情况, 经服务中心确定, 可免费维修服务;

质保性能故障

- 1. 产品不通电, 或通电无法正常开机;
- 2. 设备按键无法正常使用;
- 3. 其他硬件故障导致的产品功能无法正常使用;

非质保范围

- 1. 未经授权的维修、误用、碰撞、滥用、进液、事故、改动、不正确的使用非本产品配件, 或撕毁、涂改标贴、防伪标记;
- 2. 已超过三包有效期;
- 3. 火灾、水灾、雷击等不可抗力造成的损坏不符合故障的情况;
- 4. 因人为原因导致本产品及配件产生性能故障;

承诺与声明

本公司保证其所生产的产品均符合国家标准, 对任何非本公司直接发表的与产品相关申明, 本公司将不承担任何义务;

TUYA CURTAIN MOTOR

Zigbee


INSTRUCTIONS



---ABSORBED · INNOVATE · THE ACME---

According to the company's business development, the product may be adjusted from time to time, and the specific functions and contents may be adjusted dynamically. The company cannot guarantee that the relevant packaging and instructions updated in time. Customers please use in practical. The functions and contents shall prevail.

Structural description




Basic parameters

Product model	CMD900E	Radio frequency	2.4G/433MHz	Maximum width	12m
Rated power	45W/60W	Maximum payload	50Kg	Protection grade	20IP
Rated current	0.14A	Fuselage weight	1.05Kg	Running time	>4min
Rated torque	1.2Nm/2.0Nm	Operation noise	33dB	Working temperature	-10℃~50℃
Running speed	14cm/s	Minimum width	0.9m	Power line type	2 CORE
Working voltage	100~240Vac 50/60Hz				


Functional characteristics

- Touch start function
 - Power failure pull function
 - Resistance And Stop Function
 - Run gracefully
 - Fabric rebound correction function
 - Stroke fine tuning function
 - Electronic memory limit
- Remote control
 - Timing control
 - Speech control
 - Positive inversion settings
 - Calibration function


Motor installation



Check whether the pull-out lock rod is in the schematic position. If on the right side of the diagram, pull the pull-out lock rod while pulling it to the left.




The motor is inserted into the main transmission box.




Pull out the locking rod to the right until the rod head falls into the right limit hole.


Motor disassembly




Pull down the locking rod downward to make the top slide out of the limit hole.



Pull and pull the lock bar to the left side.



Remove the motor.




Pull out lock rod




Be careful

- Install according to the size requirements in the illustration.
- Ensure the position of the pullout lock rod in the illustration.
- The ceiling of the motor must be strong enough to withstand all the weight including the guide rail, motor and curtain cloth.


Remote control pair code




Motor and remote control counter code



Electrify the motor




Press the function key of the motor More than 3 seconds, the indicator light




Press the open button of the remote control, the code is successful

Motor and remote control decoding




Electrify condition, press function key above 3 seconds, wait for indicator lamp to often light.



Continue to press the function key for more than 5 seconds, wait for the indicator light to flash quickly, complete the clearance function.

Commutation of motor operation




Quickly press the function key once, then press and hold it again, The motor shakes and the commutation is successful.

The product uses graffiti intelligent system control, please download graffiti smart APP.

Electric motor networking



Scanning two-dimensional code, downloading and installing graffiti smart APP or searching and downloading in the mobile application market, and registering account login.



Press the function key of the Motor 3 times quickly, Press long again and keep the light blinking



in Tuya smart app intelligent gateway press [Add Subdevice] to add device.



Select "curtains", confirm the device status according to the page instructions, click confirmation to enter the network.



Enter the password, click confirm, make the distribution network.



Waiting for the connection to be successful, you can control it on APP and customize the setting name.

The way to solve the net problem is

There are two ways to solve the intelligent switch network :

Method 1: on mobile APP, remove the device to be removed, click the upper right corner.  ,Select "remove equipment";

Method 2: Release the curtain motor, press the reset key of the motor three times in a row, and then press it for a long time until flash, then the equipment will be relieved.

Device sharing:

Enter the device on graffiti APP and click on the top right side.  Select "share device", then "add share", add the account you want to add to it.

Speech control method

Graffiti intelligent curtain motor supports a variety of voice box control: Tmall elves | Little love classmate| takki | Amazon | Google Home

1. intelligent curtain motor through "graffiti intelligence" APP networking.
2. bind the account of graffiti intelligence to the APP of each voice box, that is, the corresponding voice control.

Example 1: Tmall elf control

1. intelligent curtain motor through "graffiti intelligence" APP networking.
2. open the Tmall elf APP. Click on my "add device" to bind the platform account. Find "graffiti intelligence" to bind. After binding, you can control Tmall elf.


For exampe, 2: little love classmates control.

1. intelligent curtain motor through "graffiti intelligence"APP networking.
2. open "Mi jia "APP.Click on "mine" — "Set up" —" Laboratory function"
— "Third party platform"—Add "find" graffiti intelligence "to bind.
After binding, you can control your classmtes.

Inventory

1. intelligent curtain motor;
2. power cord.
3. a user manual.

Interface description



After sale policy

Three package provisions

1. Within 7 days from the date of your signature and receipt, if there is a performance failure of this product, the service center will confirm that it can enjoy free return or exchange services.
2. Within 8-15 days from the date of your signature, if there is a performance failure of this product, the service center will determine that it can enjoy free exchange or maintenance services.
3. Within 36 months from the date of your signing and receiving, the product has performance failures, which can be repaired free of charge by the service center.

Quality assurance performance failure

1. the product is not energized, or the power fails to start properly.
2. the key of the device can not be used normally.
3. the function of other products caused by other hardware failures can not be used normally.

Non warranty range

1. Unauthorized maintenance, misuse, collision, abuse, infusion, accident, alteration, incorrect use of non-product accessories, or tear, alter labels, anti-counterfeiting marks;
2. more than three packages are valid.
3. the damage caused by force majeure, such as fire, flood and lightning strikes, is not in line with the situation of failure.
4. failure of the product and accessories due to human causes.

Commitment and statement

The company guarantees that the products conform to the national standards. The company will not undertake any obligations for any declarations related to products that are not directly issued by the company.